



Dell Precision M4700 Base Cover Replacement


Written By: Johnathan Hammond



 **TOOLS:**

- Phillips #0 Screwdriver (1)

Step 1 — Battery



- Slide the release latch to unlock the battery.
- Flip and remove the battery from the computer.

Step 2 — Base Cover



- Remove the screws that secure the base cover to the computer. Press the rubber tabs towards the rear of the computer to disengage the base cover.
- Flip and remove the base cover from the computer.

To reassemble your device, follow these instructions in reverse order.