



Dell Precision M4700 Battery Replacement

Written By: Johnathan Hammond



Step 1 — Battery



- Slide the release latch to unlock the battery.
- Flip and remove the battery from the computer.

To reassemble your device, follow these instructions in reverse order.