




Dell Precision M6400 Base Cover Replacement


Written By: Johnathan Hammond



 **TOOLS:**


- Phillips #0 Screwdriver (1)

Step 1 — Battery



- Slide the battery release latch and remove the battery.

Step 2 — Base Cover



- Remove the two M2 x 3-mm screws.
- Slide the cover toward the front of the computer to release the tabs from the base assembly.
- Remove the cover from the base assembly.

To reassemble your device, follow these instructions in reverse order.