



Dell Precision M6600 LCD Replacement

Follow these steps if you need to replace your computer screen.

Written By: Kaley Lindsay



 **TOOLS:**

- Essential Electronics Toolkit (1)

Step 1 — LCD




- Open the laptop and make sure the battery is not plugged in.

Step 2




- Using the iFixit opening tool, take the plastic around the screen off.

Step 3



- Unscrew all the highlighted areas so the screen is unattached from the plastic.

Step 4



- You can now carefully pull the golden cable out from the screen. The screen will then be able to be replaced

To reassemble your device, follow these instructions in reverse order.