



Dell Precision M6700 Base Cover Replacement

Written By: Johnathan Hammond





TOOLS:


- [Phillips #0 Screwdriver](#) (1)
-

Step 1 — Battery



- Slide the release latch to unlock the battery.
- Flip and remove the battery from the computer.

Step 2 — Base Cover



- Remove the screws that secure the base cover to the computer. Press the rubber tabs towards the rear of the computer to disengage the base cover.
- Flip and remove the base cover from the computer

To reassemble your device, follow these instructions in reverse order.