



# Dell Precision T3400 Power Supply Replacement

This guide provides the information needed to successfully replace the power supply in the Dell Precision T3400 desktop computer.

Written By: Josette Cormier



This document was generated on 2019-11-08 12:47:19 PM (MST).


 **TOOLS:**

- Phillips #2 Screwdriver (1)

 **PARTS:**

- Power Supply (1)

## Step 1 — Disconnect the DC power cables from the system board and the drives.



- Pay special attention to where the DC power cables are plugged in so that they can be replaced the same way.


*ⓘ* You may need to **remove the heat-sink assembly** in order to detach certain cables.

## Step 2 — Remove the power supply from the computer case.



- Remove the four screws on the back of the power supply using a standard Phillips-head screwdriver.

## Step 3 — Remove the power supply from the computer case.




- Press the secure tab down and slide the power supply out of its bracket to remove it.

## Step 4 — Install the new power supply.



- Slide the power supply into the empty bracket. It will click into place.
- Replace the four screws to secure the power supply to the computer case.

## Step 5 — Reconnect the DC power cables.



- Remember to use the case's secure tabs to hold cables out of the way.
- If you removed the heat-sink assembly in order to remove any power supply cables, be sure to **re-install the assembly**.

To reassemble your device, follow these instructions in reverse order.