



# Dell Studio 1537 Back Cover Replacement

Prerequisite Only - Shows how to remove the back cover and expose most of the internal components.

Written By: Zach Dylag





## INTRODUCTION

Prerequisite Only - The back cover is responsible for adding structural support and protecting the internal components. After removing the cover, removing the hard-drive, RAM, and Disk-Drive become possible.

### TOOLS:

- Phillips #0 Screwdriver (1)

## Step 1 — Battery



⚠ Ensure the laptop is turned off and unplugged before attempting to remove any piece.

- Place the laptop lid down so the underside is visible.
- Pull battery release switch and gently pull the battery directly away from the switch.

## Step 2 — Back Cover



- Identify the back cover of the laptop.

## Step 3



- Unscrew and remove all of the 6.0mm screws with a Phillips #1 screwdriver.

## Step 4



- Lift the back cover off of the laptop.

To reassemble your device, follow these instructions in reverse order.