



Dell VRC100-R Battery Replacement

How to replace the batteries of the Dell VRC 100-R controller to restore power.

Written By: Kenneth Liu



INTRODUCTION

If your controller does not turn on, you've come to the right place. This guide will walk you through how to replace your controller's batteries. You do not need any special tools.

Step 1 — Battery



- Orient your controller so that the black ring is on the bottom and the buttons are facing away from yourself.
- Place your thumb on the small arrow that is on the controller's battery cover and firmly push upwards.
- Slide the cover off and separate it from the controller.

Step 2



- Remove the right battery by pushing the positive end down and pulling the battery out toward yourself.
- Repeat the procedure for the left battery.

To reassemble your device, follow these instructions in reverse order.