



# Dell Vostro 1400 RAM Replacement

How to replace the RAM on the Dell Vostro 1400.

Written By: David Hogg



## INTRODUCTION

Steps on how to take out and replace the RAM drive. Follow these steps for the easiest possible way to take out and replace the RAM drive.

### TOOLS:

- [JIS Driver Set \(1\)](#)

J0

## Step 1 — Battery



**⚠** Be sure the power is off and all cables are unplugged from the device before starting.


- After flipping over the laptop, the battery is on the bottom side of the laptop.
- Find the tabs on both the left and right side of the battery.

## Step 2




- Push tabs toward the outside of the laptop until they lock in place.

## Step 3



- Push the battery forward to eject it from the laptop.


## Step 4 — RAM



**⚠** Make sure the laptop is turned off and all cables are unplugged.

- Loosen the three 3 mm screws on the RAM cover.
- *i* Screws will not completely come out.
- Lift the cover and remove it from the laptop.

## Step 5



- Pull tabs apart on both the top and bottom of the memory card.
- Lift memory card and remove it from the laptop.
- Repeat the process for the second memory card.

To reassemble your device, follow these instructions in reverse order.