




Dell Vostro 1710 Back Panel Replacement

A guide to remove the back panel that gives the user access to the motherboard and its components.

Written By: Jeremy Campeau




INTRODUCTION

The back panel has to be removed in order to be able to replace components like the RAM, fan, and heat sink.

TOOLS:

- [Phillips #1 Screwdriver \(1\)](#)

Step 1 — Back Panel



- Unscrew the eight 6mm screws with a Philips #1 screw driver.

Step 2



- Lift back cover from the groove on the left side of the cover next to the symbol.

To reassemble your device, follow these instructions in reverse order.