



Dell Vostro 2420 Keyboard Replacement

Written By: Johnathan Hammond



INTRODUCTION

In this guide, we will show you how to remove and replace the Keyboard.

TOOLS:

- [Spudger \(1\)](#)

Step 1 — Sliding the Latches



- Slide the release latches to unlock the battery.

Step 2 — Sliding the Battery



- Slide the battery and remove it from the computer.

Step 3 — Prying the Keyboard




- Starting on the right, pry up the keyboard from the computer.

Step 4 — Flip the Keyboard



- Flip the keyboard over and lay it on the palmrest.

Step 5 — Disconnect the Keyboard Cable



- Disconnect the keyboard cable from the system board.

Step 6 — Remove the Keyboard



- Remove the keyboard from the computer.