




Dell Vostro 3550 Keyboard Replacement

Use this guide to replace the keyboard of the Dell Vostro 3550.

Written By: Sean Stonehouse



INTRODUCTION

This guide will walk through all the necessary steps in order to replace the keyboard for the Dell Vostro 3550. The keyboard may need to be replaced if multiple keys don't function, the entire keyboard does not function, or to access screws for the motherboard.

TOOLS:


- Metal Spudger (1)

Step 1 — Unlocking the Battery




- Slide the release latches to unlock the battery.

Step 2 — Sliding the Battery




- Slide the battery and remove it from the computer.

Step 3 — Keyboard




- Turn the laptop right side up. Open the display to reveal the keyboard.
- Use the metal spudger to pry the keyboard upward from the base. Make sure to pop each of the three clips keeping the keyboard in place.

Step 4



- Carefully lift the keyboard upward to reveal the keyboard ribbon cable.

Step 5



- Lift the black tab on the keyboard cable connector upwards to release the cable.

Step 6



- Pull the ribbon cable away from the connector.
- Remove the keyboard.

To reassemble your device, follow these instructions in reverse order.