




Dell Vostro A840 Hard Drive Replacement

How to replace the hard drive of a Dell Vostro A840.

Written By: Johnathan Hammond




INTRODUCTION

In this guide, we will be showing you how to remove and replace the Hard Drive.

TOOLS:

- Essential Electronics Toolkit (1)


Step 1 — Remove the battery



- Unlock the battery by sliding the battery-lock latch towards the outer edge.
- Slide the battery-bay release latch and hold it.
- Remove the battery from the battery bay.

 If this is all you are doing Follow Step In Reverse if not Go to Next Step.

Step 2 — Removing the Hard Drive



- Remove the two screws securing the hard drive assembly to the system board.
- Holding the connector end of the hard drive assembly, pull the hard drive assembly from the system board connector.

Step 3 — Removing the Hard Drive



- Press down on the hard drive at the non-connector end slot to remove the hard drive off the hard drive cage.