




Dell Vostro A840 Module Cover Replacement

Written By: Johnathan Hammond




INTRODUCTION

In this guide, we will be showing you how to remove and replace the Module Cover.

TOOLS:

- Phillips #0 Screwdriver (1)


Step 1 — Remove the battery



- Unlock the battery by sliding the battery-lock latch towards the outer edge.
- Slide the battery-bay release latch and hold it.
- Remove the battery from the battery bay.

☞ If this is all you are doing Follow Step In Reverse if not Go to Next Step.

Step 2 — Remove the Module Cover



- Remove the two screws from the module cover.
- Lift the module cover away from the computer.

☞ If this is all you are doing Follow Step In Reverse if not Go to Next Step.