



# Dell Vostro V130 LED Cover Replacement

Written By: Johnathan Hammond



## INTRODUCTION

In this guide, we will show you how to remove and replace the LED Cover.

### TOOLS:

- Phillips #0 Screwdriver (1)

## Step 1 — Remove the Screws



- Remove the screws that secure the base cover to the computer.

## Step 2 — Removing the Base Cover



- Slide the base cover towards the front of the computer. Lift it up and away from the computer.
- If this is all you are doing Follow Step In Reverse if not Go to Next Step.

## Step 3 — Disconnecting the Battery



- Lift the black cable-release clip to release the battery cable from the connector on the system board and disconnect the battery cable.

## Step 4 — Remove Battery Screws



- Remove the screws that secure the battery to the computer.

## Step 5 — Lift the Battery



- Lift the battery up and away from the computer.

► If this is all you are doing Follow Step In Reverse if not Go to Next Step.

## Step 6 — LED Cover



- Starting on the right side of the system, use a plastic scribe to pry up the LED cover from the computer.

## Step 7 — Removing the LED Cover



- Pull the LED cover toward the keyboard and remove it from the computer.

 If this is all you are doing Follow Step In Reverse if not Go to Next Step.