




# Dell XPS 11 9P33 Battery Replacement

Written By: Johnathan Hammond




## INTRODUCTION

In this guide, we will show you how to remove and replace the Battery.

### TOOLS:

- [Phillips #0 Screwdriver \(1\)](#)

## Step 1 — Removing the Battery



- Disconnect the battery cable from the system board.
- Remove the screws that secure the battery to the palm-rest assembly.
- Lift the battery, along with its cable, off the palm-rest assembly.

**i** Turn the computer over, open the display, and press the power button for about five seconds to ground the system board.

**↗** If this is all you are doing Follow Step In Reverse if not Go to Next Step.