



Dell XPS 14 L401X Battery Replacement

How to replace a faulty battery in the Dell XPS 14 L401X.

Written By: Mark




INTRODUCTION

If your laptop is suffering from a faulty battery, it might be time for a replacement. Make sure the laptop is completely turned off before attempting to replace the battery.

Step 1 — Battery



 Make sure that the laptop is shut off before attempting to remove any components from the device.

 The laptop in this example did not have a battery equipped.

- Locate the spring latch on the bottom of the device that will unlatch the battery.
- Hold the spring latch in the open position with one hand, and support the battery with the other hand.
- Turn the laptop over and allow the battery to fall out of its holder and into your hand.

To reassemble your device, follow these instructions in reverse order.