



# Dell XPS 17 L702X Battery Replacement

A guide to replace battery for the Dell XPS 17 L702X

Written By: Shin Sul



## Step 1 — Battery




- Flip over the laptop so that the bottom battery compartment faces upwards.

## Step 2



- Slide the tab below the battery to the left and hold the tab in place.

## Step 3



- While holding the tab, lift the battery out of its compartment.
- Release the tab after removing the battery.

To reassemble your device, follow these instructions in reverse order.