



Dell XPS M1330 Hard Drive Replacement

How to replace a Dell XPS M1330 hard drive.

Written By: Kai Kapossy



INTRODUCTION

If your computer were to experience any unexpected crashes or viruses follow this guide to remove and replace the hard drive.

TOOLS:

- [Phillips #1 Screwdriver \(1\)](#)

PARTS:

- [Dell XPS M1330 Hard Drive \(1\)](#)

Step 1 — Battery



- Flip the laptop on its back, so that the underside is facing up.

Step 2



- Push and hold the slide button to the left and unlock the mechanism.

Step 3



- Lift the computer up and slowly pull the battery straight out from the device.

Step 4 — Hard Drive



- Flip the laptop on its back, so that the underside is facing up

Step 5



- Remove the four 3.0mm Phillips #1 screws securing the hard drive casing.

Step 6



- Slide the hard drive away from the computer, slowly and carefully.

To reassemble your device, follow these instructions in reverse order.