



# Dell XPS M140 Hard Drive Disk (HDD) Replacement

This guide will help users locate and remove the HDD.

Written By: Travis Morazzini



## INTRODUCTION

In this Guide, a user will be able to safely access/replace the Hard Disk Drive (HDD) in their Dell XPS M140 laptop, if needed. This Step-wise guide provides detailed imaging of disassembly, cautioning of notable components, and exact notations for accessing Dell XPS M140 HDD.

### TOOLS:


- [Phillips #0 Screwdriver](#) (1)
- [Phillips #00 Screwdriver](#) (1)

## Step 1 — Battery



- The first step is to turn over the laptop

## Step 2



- locate the slide lock for the battery.

## Step 3




- Slide the lock and pull out the battery.

## Step 4 — Hard Disk Drive (HDD)



- Loosen the two screws that secure the hard drive cover.
- The screws won't come out fully. Once you feel like the door is loose enough, it should come right off.

## Step 5



- Remove the old HDD from the casing.
- It should just slide out of it's connection.

To reassemble your device, follow these instructions in reverse order.