





# Dell XPS M1730 Battery Removal

Replace Battery

Written By: Johnathan Hammond



## Step 1 — Dell XPS M1730 Battery Removal



- Disconnect your computer and all attached devices from their electrical outlets.
- Slide the battery-bay release latch on the bottom of the computer.
- Remove the battery from the battery bay.

To reassemble your device, follow these instructions in reverse order.