




Dell chromebook 3180 Battery Replacement

This guide will show you how to replace the battery.

Written By: Jon



INTRODUCTION

This guide will show you how to replace the battery.


TOOLS:

- [Phillips #0 Screwdriver](#) (1)
- [Plastic blade](#) (1)
- [Phillips #00 Screwdriver](#) (1)

PARTS:

- [42Wh Dell Battery Type 51KD7](#) (1)

Step 1 — Remove Battery Screws



- Remove the 3 battery screws with a phillips #00 screwdriver.

Step 2 — Remove Battery



- Remove the battery from the motherboard extension connector

To reassemble your device, follow these instructions in reverse order.