




# Dewalt DCF885 Brush Assembly Replacement

This guide will instruct you how to remove the brush assembly.

Written By: Landon Smith



 **TOOLS:**

- [T10 Torx Screwdriver \(1\)](#)
- [ESD-safe pry tool \(1\)](#)

## Step 1 — Battery



- Press the battery release button at the top of the battery.

## Step 2




- Pull the battery away from the tool.

## Step 3 — Motor Assembly



- Remove the eight 18 mm Torx Security #10 screws.

## Step 4



- Separate the two halves of the outer case. Set the empty side down and out of the way.

## Step 5




- Disconnect the connector from the motor assembly.

## Step 6




- Pull the motor away from the brush assembly.

## Step 7 — Brush Assembly




- Lift the brush assembly out of the drill case.

## Step 8




- Pull the armature assembly apart from the brush ring assembly.

## Step 9



- Pry the two circled connectors apart from the brush ring assembly.

## Step 10



- The brush assembly is now removed from the drill body.

To reassemble your device, follow these instructions in reverse order.