




# Digiland DL8006 Battery Replacement

How to replace a Digiland DL8006 battery.

Written By: Landon Choi



## INTRODUCTION

This guide will go into detail with replacing the internal battery of DigiLand DL8006.

### **TOOLS:**

- [iFixit Opening Tools](#) (1)
- [Tweezers](#) (1)
- [Phillips #0 Screwdriver](#) (1)

### **PARTS:**

- [digiland dl8006 battery](#) (1)

## Step 1 — Battery





- Place the device down on its front with the back facing upward.
- Split the two faces of the device with a plastic opening tool to pry the back cover off.
- Remove the silver/metallic tape covering the bottom end of the tablet.

## Step 2



- Remove the red & black wire that connects the motherboard to the bottom end of the tablet.
- Remove the ribbon cable over the battery by flipping up the plastic tab on the ZIF connector on either side of the cable and pulling it out.

## Step 3



- Remove the red & blue cord connecting the battery to the motherboard.
- Remove the tape connecting the motherboard to the back of the LED screen.
- Pry open with a plastic opening tool along the top and bottom edges until the battery is free from the device.
- Remove all the remaining tape from the battery.

**i** It may be helpful to [remove the motherboard](#) prior to prying the battery out for better leverage on the edges.

To reassemble your device, follow these instructions in reverse order.