



Dirt Devil Vibe Vacuum Brush Roller Replacement

Use this guide to replace the brush roller on your Dirt Devil Vibe vacuum.

Written By: Michell Lopez



INTRODUCTION

Use this guide to replace the brush roller on your Dirt Devil Vibe vacuum when the brush on your vacuum gets clogged. This repair solves brushes that spin slow, or do not spin at all. There are no special skills required.



TOOLS:


- [Phillips #0 Screwdriver](#) (1)
-

Step 1 — The Brush Roller



- Lay the vacuum so it's facing up.

Step 2




- Use a Phillips #0 screwdriver to remove each screw.

Step 3




- After removing all of the screws pull the vacuum's black cover up to remove it.

Step 4



- Pull the brush roll up to remove from the black cover.

Step 5



- Replace the brush roll with a new brush roll.

To reassemble your device, follow these instructions in reverse order.