



# Disassembling CygoLite Night Rover Top Casing

This guide will show how to remove the top casing of the CygoLite Night Rover bicycle light.

Written By: Lauren Noble



 **TOOLS:**

- Phillips #0 Screwdriver (1)

## Step 1 — Disassembling CygoLite Top Casing



- Place device face down on flat surface.
- Note placement of screws and use a Phillips head screwdriver to remove the screws.
- Lift away top casing.

To reassemble your device, follow these instructions in reverse order.