




# Disassembling Dell Inspiron One 2020 Back Cover

How to remove the stand and back cover. This will always be the first step in accessing the internals of this all in one.

Written By: Tyler



This document was generated on 2019-09-18 02:27:11 AM (MST).

 **TOOLS:**

- **Spudger** (1)
- **Phillips #2 Screwdriver** (1)

## Step 1 — Back Cover



 Place the all in one computer face down on a soft, clean surface to avoid scratching the front.

- Press the tab on the stand cover and lift up.

## Step 2



- Remove the four phillips screws that attach the stand to the computer.
- Tilt the stand up and out.

## Step 3



- Starting from the optical drive, pry the back cover up with a plastic spudger.
- ⓘ The cover is held in place by fragile plastic clips. Careful to not break them.

To reassemble your device, follow these instructions in reverse order.