



# Disassembling GravityLight Front Panel

Prerequisite Only


Written By: Michallynn Hoffman



 **TOOLS:**

- **Phillips #00 Screwdriver (1)**

## Step 1 — Removing the Front Panel



- Flip the GravityLight on its back and place it on a sturdy surface.
- Unscrew the three 2cm Phillips #00 screws on the back of the GravityLight's body.

## Step 2 — Opening the Device Housing



**⚠** Some of the internal pieces may loosen or fall out during disassembly.

- Firmly grasp both parts of the GravityLight body and pull them apart.

To reassemble your device, follow these instructions in reverse order.