




Disassembling IBM ThinkPad T42 Rear Cover

Written By: Gerald Watanabe



INTRODUCTION

The disassembly of the rear cover is simple but requires the removal of a lot of screws.

TOOLS:


- Phillips #0 Screwdriver (1)

Step 1 — Bottom Cover



- Unscrew the 20 Phillips screws on the underside of the T42.
- (i)* For ease of reassembly, keep your screws organized.

Step 2 — Rear Screws



- Unscrew the 2 Phillips screws on both sides of the T42's rear.

To reassemble your device, follow these instructions in reverse order.