



Disassembling Kodak Advantix F350 Battery

This guide demonstrates how to install the camera battery.

Written By: David Cottrell



 **TOOLS:**

- [iFixit Opening Tools \(1\)](#)

Step 1 — Disassembling Kodak Advantix F350 Battery




- Turn off camera by moving the highlighted switch to the O-Position.

Step 2



- To open the cover of the battery slot, push the highlighted tab in the direction of the arrow next to it, and gently lift.

Step 3



- Use your plastic opening tool to slowly pry the battery from the camera case.
- With your fingers, remove the battery and replace with new one.
- Gently close the cover of the battery slot.