



Disassembling Nexus 4 Case, USB Flex, Mainboard, Headphone Jack, Screen etc.

A full video guide for disassembling, removing and replacing internal parts.

Written By: LE55ONS




INTRODUCTION

[video: <http://www.youtube.com/watch?v=AZDAlgwbXk4>]

TOOLS:

- [Flathead Screwdriver](#) (1)
- [iFixit Opening Tools](#) (1)
- [T5 Torx Screwdriver](#) (1)
- [Phillips #00 Screwdriver](#) (1)

Step 1 — Case, Battery, USB Flex, Mainboard, Headphone Jack, Screen etc.



- Opening the case

To reassemble your device, follow the complete video