




Disassembling Nokia 6590i Keypad, Speaker, and Screen Assembly

Remove the keypad, speaker, and screen assembly.

Written By: Colby Leslie




INTRODUCTION

This guide will show you how to remove the assembly that houses the phone's keypad, speaker and screen.

TOOLS:


- [Spudger](#) (1)
- [T6 Torx Screwdriver](#) (1)

Step 1 — Battery



- Press the button to remove the back cover.
- Pull the cover downward and lift it off while still pressing the button.

Step 2



- Lift the battery out of the phone by pushing down from the top and pulling out

Step 3 — Keypad, Speaker, and Screen Assembly



- Grip the front cover from the bottom.

Step 4




- Lift the front cover off.

Step 5




- Locate 6 screws on front of assembly and unscrew them using a T6 torx screwdriver.

Step 6



- Insert spudger along edge of assembly and gently lift assembly away from case

Step 7



- Remove assembly from phone

To reassemble your device, follow these instructions in reverse order.