




Disassembling Numark TT1600 Circuit board

This guide will show how to remove the circuit boards.


Written By: Sukhjinder



 **TOOLS:**

- **Phillips #00 Screwdriver (1)**

Step 1 — Circuit board




- Flip over the turntable and remove the nine screws on the outer edges.

Step 2




- Remove the back cover by pulling it apart.

Step 3





- Locate the largest circuit board inside the device.

Step 4




- Locate the wires that are plugged into the side of the circuit board.

Step 5



- Gently pull out the wires plugged into the circuit board.

Step 6



- Once the wires are unplugged you will notice two more wires plugged into the bottom of the circuit board.

⚠ Note that these wires are soldered onto the circuit, indicated by the red markers.

- To completely remove the circuit board these wires must be removed.

To reassemble your device, follow these instructions in reverse order.