



Disassembling Samsung Gravity SGH-T459

Rear Case

This guide will help disassemble the rear case from the rest of the cell phone.

Written By: William Glatz



INTRODUCTION

This guide will teach you how disassemble and reassemble the rear case to your Samsung Gravity SGH-T459.

TOOLS:

- [Phillips #1 Screwdriver](#) (1)
- [iFixit Opening Tools](#) (1)

Step 1 — Disassembling Samsung Gravity SGH-T459 Back Cover



- Press and hold the End key to power down the cell phone.
- Gently remove the back cover with your fingers by sliding it in the direction of the arrows.

Step 2 — Disassembling Samsung Gravity SGH-T459 Battery



- Gently lift up and remove battery with your fingers in the direction of the arrows.

Step 3 — Rear Case



- Hold the cell phone steady with one hand. With the other hand, use a Phillips screwdriver to remove all 6 screws around the edges of the rear case.
- Slide the phone open.
- Use a plastic prying tool to pry open the edge of the green trim near the space bar of the keypad. You should hear the rear case unsnap.
- Gently lift and remove the rear case from the cell phone.

To reassemble your device, follow these instructions in reverse order.