



Disassembling Xbox 360 E Top Panel

Remove the top panel of the Xbox 360 E. Note: Disassembly of your Xbox 360 E will void your warranty.

Written By: Jennifer



INTRODUCTION

This guide is a prerequisite for replacing other parts of an Xbox 360 E.

TOOLS:

- [Spudger \(1\)](#)

Step 1 — Top Panel



- Push the [Spudger](#) into the crevice between the grated top panel of the Xbox and the bottom body with the rubber feet.
- Pull back on the spudger like a lever, keeping it pressed firmly into the crevice.

Step 2



- Slide the spudger along the separation you have created between the grated panel and the bottom body of the Xbox.
- Periodically pull back on the spudger like a lever, keeping it pressed firmly into the crevice.

Step 3



- Continue sliding the spudger along the perimeter of the left grated face of the Xbox.
- Pull the top panel off.

To reassemble your device, follow these instructions in reverse order.