



# Disassembling ZTE GRAND S FLEX : Unibody, Battery, Motherboard

Explain how to open the uni-body shell of the ZTE Grand S Flex. How to disassembling different components as Battery, Camera, Antenna,... At the final stage, the motherboard and the screen will be isolated.

Written By: Jonathan J

**5. Motherboard without shell**

 **TOOLS:**

- Pro Tech Toolkit (1)

## Step 1 — Disassembling ZTE GRAND S FLEX : Unibody, Battery, Motherboard

### 1. Unpast the black part

Introduce something sharp carefully into the hole of the micro to lift the black cover

Do not go too far, otherwise you will damage the micro



- Insert wisdom here.

## Step 2


### 2. Unscrew the two long screws



- Insert wisdom here.

## Step 3

- Insert wisdom here.



## Step 4

- Insert wisdom here.




## Step 5



- Insert wisdom here.

## Step 6



- Insert wisdom here.

## Step 7



- Insert wisdom here.

## Step 8



- Insert wisdom here.

## Step 9



- Insert wisdom here.

To reassemble your device, follow these instructions in reverse order.