




# Disconnecting Microphone from Motherboard

Prerequisite guide for any step involving disconnecting the microphone

Written By: Timothy Forrest



 **TOOLS:**

- **Tweezers** (1)
- **Phillips #0 Screwdriver** (1)

## Step 1 — Front and Back Cover




- Remove the two 8 mm Phillips #0 screws on the back cover.

**⚠** The motherboard is attaching the two covers together, so don't separate them entirely just yet.

**ⓘ** There is a button that loosens as the Phillips screws are removed. Don't be alarmed if it falls out.


## Step 2



- Remove the four 6mm Phillips#0 screws connecting the motherboard and front cover.

**⚠ DO NOT** detach the wire connecting the motherboard to the front cover.

## Step 3 — Microphone Connection



- Grasp the white wire connector between the tabs and the socket.
- Wiggle the connector back and forth to remove the front cover from the motherboard.

To reassemble your device, follow these instructions in reverse order.