



Dragon Touch Back Cover Replacement

This guide will provide instructions on how to remove the back cover of the Dragon Touch MID 7138.

Written By: Nicholas Reas



INTRODUCTION

This guide will provide instructions on how to remove the back cover of the Dragon Touch MID 7138.

TOOLS:

- [iFixit Opening Tools](#) (1)

Step 1 — Back Cover



- Wedge a plastic spudger between the back panel and the screen to begin lifting the back cover.
- Wedge around all edges until the back cover pops off entirely.

Step 2



- Gently pry the back cover from the screen using your hands.

To reassemble your device, follow these instructions in reverse order.