



Dragon Touch MID 7138 Display Panel Replacement

This replace guide provides instructions to remove the existing display on your device.

Written By: Nicholas Reas




INTRODUCTION

Need to replace the display of your device? This guide provides instructions on how to remove the existing display on your Dragon Touch MID 7138.

TOOLS:

- [Hair Dryer](#) (1)
- [Spudger](#) (1)

Step 1 — Display Panel



- Insert metal spudger under the screen to begin prying the screen off.

 Make sure hands are away from glass to prevent possible cuts.

Step 2



- Use a hair dryer to heat up the glass.
- Use metal spudger to continue pulling glass off slowly.

To reassemble your device, follow these instructions in reverse order.