



Dyson V6 Motorhead Connection Tubing Replacement

Connection tube may break or clog with heavy usage. This replacement guide will create easier access to clean your tube or replacement if necessary.

Written By: Addie Hedge



INTRODUCTION

Connection tube may get clogged with large debris picked up while vacuuming or damaged overtime.

Step 1 — Connection Tubing



- Depress the button releasing an end of the connection tubing.
- Pull the connection tubing away from the bottom vacuum head.

Step 2



- Depress the last button, freeing the connection tubing.
- Pull connection tubing away from the upper vacuum head.

To reassemble your device, follow these instructions in reverse order.