



Dyson V8 Absolute Battery Replacement

Replacing the Dyson V8 Absolute Battery.

Written By: Jasvir Dosanjh



INTRODUCTION

In case the device is not turning on and the battery has been completely charged for 5 hours, the battery may need to be replaced. The battery can be easily removed and replaced.


TOOLS:

- Phillips #2 Screwdriver (1)

PARTS:

- Dyson V8 Vacuum Battery (1)

Step 1 — Battery




 Detach wand from device.

- Use a Phillips #2 screwdriver to unscrew the screw from the device handle.

 (i) Screw Head Type: Phillips #2

 (i) Screw Length: 170mm

Step 2



- Turn device completely over to view battery pack.
- Below the bin, use a Phillips #2 screwdriver to remove both screws from the battery back.

(i) Screw Head Type: Phillips #2

(i) Screw Length: 170mm

Step 3



- Pull the battery pack down and away from the device.

⚠ Battery pack may fall out.

To reassemble your device, follow these instructions in reverse order.