



Ehang GHOSTDRONE Aerial Plus 2.0 Battery Replacement

Replace the battery on your Ehang GHOSTDRONE Aerial Plus 2.0 to bring power back to your drone.

Written By: Edrees Nawabi



This document was generated on 2019-09-18 04:48:55 AM (MST).

INTRODUCTION

Are you having battery issues? Follow this simple guide to replace the battery on your Ehang GHOSTDRONE Aerial Plus 2.0.

TOOLS:

- [iFixit Opening Tools \(1\)](#)

Step 1 — Battery



- While the drone is facing forward, pinch the two tabs on the capsule, and pull it forward.

Step 2



- The battery is in the back of the capsule.
- Pull the battery out from the back using one of the plastic tools to guide it out.

To reassemble your device, follow these instructions in reverse order.