



# Ehang GHOSTDRONE Aerial Plus 2.0 Gimbal Replacement

Replace your gimbal to continue taking great photos with your Ehang GHOSTDRONE Aerial Plus 2.0.

Written By: Eleni



This document was generated on 2019-09-17 07:51:08 PM (MST).

## INTRODUCTION

Are you having trouble taking photos with your Ehang GHOSTDRONE Aerial Plus 2.0? Follow these steps to replace the gimbal.

### TOOLS:

- 2 Hex (1)

## Step 1 — Gimbal



- Turn the drone on its back and identify the gimbal.

## Step 2



- Identify the screws on the gimbal.
- Using the Hex 2.0 on the Magnetized Driver Handle unscrew the screws counter clockwise and remove.
- Pull the gimbal upwards and off the base of the drone.

To reassemble your device, follow these instructions in reverse order.