



# Exchange Apple Keyboard Battery

Written By: Lasse



## Step 1 — Turn off the keyboard



- Turn off the keyboard

## Step 2 — Open the battery compartment



- Insert the pick in the slot on the left side of the keyboard.

- Turn it counterclockwise.

## Step 3 — Empty the battery compartment



- Empty the battery compartment

**i** There are 2 or 3 batteries in a battery compartment of a keyboard.

Repeat the steps in order to reassemble your device.