



Exchange iPhone 4S SIM card

Written By: Lasse



Step 1 — Turn iPhone off



- turn off the iPhone.

Step 2



- Press with a SIM card opener or a paper clip into the hole on the right side of the iPhone.
- pull the SIM card slot out of the case.

Step 3



- Now they have the SIM card.

Repeat the steps in order to reassemble your device.