




# Fan Replacement

Written By: Felice Suglia



 **TOOLS:**

- Phillips #0 Screwdriver (1)

**PARTS:**


- New Item (1)

## Step 1 — Battery



- Unlock the battery latch on the right.
- Unlock the battery lock on the left.
- Remove the battery pack from its slot.


## Step 2 — Access to Components 2



- Using the Philips # 0 screwdriver, unscrew the 2 screws of the top cover
- Check the marks indicating the direction in which the cover must be removed.
- Remove the bottom cover by removing it in the direction of the markers.

## Step 3

- Then appear the other components of the Laptop.




## Step 4 — Fan



- Here is the fan.
- Disconnect the power cable from this one.
- Unscrew the screws that hold it in place.

## Step 5



- Gently lift the fan out of its slot.

To reassemble your device follow the following instructions in reverse order