




Fitbit Zip Teardown

Written By: Nathanael



 **TOOLS:**


- [iFixit Tech Knife \(1\)](#)
- [Spudger \(1\)](#)

Step 1 — Fitbit Zip Teardown



- Use your iFixit Pro Tech Knife to slice and pry the different colored front and rear cases apart, as shown

Step 2



- Remove the logic board/display assembly from the rear case

Step 3



- Use your knife to slice off the bottom edge of the sticker found here on the rear of the board

Step 4



- Use a spudger to gently pry the display away from the logic board
- Pry softly in each corner of the display, under the black frame

Step 5



- Seems to be it. The display doesn't appear to be separable from the logic board, sadly, making repairability completely out of the question.