



Fix iPhone 7 Plus Touch ID/Home Button dose not return function

Fix iPhone 7 Plus Touch ID/Home Button dose not return function

Written By: gokto

The advertisement features a dark grey background. In the top left corner is the G-LON logo, which consists of a stylized 'G' inside a white circle with a blue dot, and the text 'G-LON' in blue. In the center is a blue rounded rectangle containing a detailed illustration of an iPhone 7 Plus home button assembly. The assembly includes a black home button with a silver cross, a gold-colored flex cable, and a silver-colored U10 chip. The text 'G-LON' is written vertically in large, light blue letters on the left side of the blue rectangle. Below the blue rectangle, the text '使用我们G-LON研发的指纹修复器更换U10' is written in white Chinese characters, followed by 'Replace the U10 with the fingerprint key repairer we developed' in white English text.

使用我们G-LON研发的指纹修复器更换U10
Replace the U10 with the fingerprint key repairer we developed

INTRODUCTION

Fix iPhone 7 Plus Touch ID/Home Button dose not return function

[video: <https://youtu.be/J3vy-9EUSHk>]

Step 1 — Fix iPhone 7 Plus Touch ID/Home Button dose not return function



- Fix iPhone 7 Plus Touch ID/Home Button dose not return function

To reassemble your device follow these instructions in reverse order.