



Flat Iron Disassembly

1 of the hot plate is not getting heated up

Written By: Sunitha Velicharla

INTRODUCTION

One of my plate is not getting heated and I hear continuous beep sound after the machine is turned on and it reaches the desired heat level. I have a sultra flat iron 1 inch.

Thanks

Sunitha

To reassemble your device, follow these instructions in reverse order.