FujiFilm FinePix S4500 Rubber Grip Replacement

Follow these steps to remove the rubber grip on the camera.

Written By: Vicente Rios

INTRODUCTION

Is your rubber grip peeling or torn? Use this guide to help fix or replace it.

🔧 TOOLS:

- iFixit Opening Tools (1)

Step 1 — Rubber Grip

- Use a plastic opening tool to pry up the corner of the grip.

Step 2

- Grab the lifted grip area and pull across to remove the grip from the camera.

- Make sure to use a high quality adhesive when installing or repairing the grip.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2019-10-08 07:37:33 PM (MST).